

## **VW T5 1.9TDI 84HP**

1. Box type: VT101301.

2. Find plug for injector harness. Disconnect it and connect box adapter between.



3. Connect black (-) and red (+) wires to battery.