

Alfa Romeo 156 2.4 JTD 2001

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

