

BMW 118td 122HP 2006

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

