

## Land Rover 2.0D 112KM

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

