

## Mercedes E 290TD

ECU connector:

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 |
| 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 |    |
| 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |    |

Connections:

| ECU pin no. | Function          | Wire color in box harness |
|-------------|-------------------|---------------------------|
| 55          | Power +12V        | Red                       |
| 4           | Ground            | Black                     |
| 9           | Signal 1          | Yellow                    |
| 46          | Signal 2          | Blue                      |
| 22          | MAP sensor signal | White                     |