

## Mitsubishi Outlander 2.0Di-D 136HP 2007

1. Find plug for injector harness. Disconnect it and connect box adapter between.



2. Connect black and red wires to battery.