

Jaguar S-Type 2.7 D 2004

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

