

## Peugeot Boxer 2.8 Hdi 2002-2006

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

